





Mudr Wall Wash 2 in. - Fixture



1. Before installing the tape light in the channel, test the connection to power. If using a full spool of tape, connect one end of the tape to DC power and turn power on. If using a cut section of tape, attach the connector to the tape and then connect to DC power.
2. Position the 24V DC Class 2 power supply in a suitable location within 30 feet of the desired fixture location.




Note: Longer distances are acceptable when using a thicker 12 AWG wire.



3. Cut a 2.75 in. opening where you would like to mount the fixture. Recommended distance is 12 in. - 18 in. from the wall to be washed.

4. Bring power to a point through the drywall that will match the position of the fixture's cable conduit.

5. Drill a 1/4 in. hole through the back of the fixture, this will be used for the power feed. Deburr any sharp edges.




6. Assemble each end cap at the ends of the fixture with two flat head screws provided. Assemble the mud-in end cap for short run configurations.


7. Carefully countersink the holes in the mud-in flanges where the drywall screws will be placed.

8. Pass the low-voltage power wires from the LED tape through the hole. Connect LED tape lead to low-voltage in-wall rated wire. Red is positive (+) and black is negative (-).


Mudr Wall Wash 2 in. - Fixture




9. Secure the fixture to the drywall using drywall screws at the countersink points. Recommended screw spacing is every 4 in.




10. Remove the adhesive backing from the back of the LED tape. Apply the tape light to the inside and pass the lead wire to the back.




11. Install the LED diffuser. Then cover the lens with painter's tape if necessary, to prevent joint compound and dust from entering.




12. Apply drywall tape along the edges of the fixture to prevent the joint compound from cracking after installation, and smooth the tape flush.



13. Apply joint compound mud to the mud-in flanges with a joint knife, covering the flanges and screw heads, and smooth the mud joint.



14. Once dry, use the hand sander to smooth the mud to make a seamless look with the drywall. Then remove the painter's tape.



15. Paint or finish the wall as desired. Turn on lights.